

Decorator Switch (Single, Double)

Traditional decorator look outside, wireless radio-frequency technology inside.

Verve® Decorator Switches may look like traditional decorator switches but it's what they don't have that makes them special – no wires and no batteries. Verve® Decorator Switches are wireless and can be installed anywhere you need them in minutes because there is never a need to run additional wiring. The simple act of pressing the rocker creates enough energy to send a radio signal to other Verve sensors and controls to set back temperature and turn off lighting and other electric loads. Because they are self-powered they require no batteries and the costs associated with on-going maintenance and periodic battery replacements are eliminated. Place them next to existing decorator switches or anywhere you need to add a switch for efficiency and convenience.

Features & Benefits

- Communicates wirelessly with other Verve devices using EnOcean radio frequency technology.
- Wireless no additional wire to run so installation is fast and easy.
 Install them where you want them and then move them anytime.
- Self-powered no batteries to replace and no on-going maintenance.
- Capable of performing switching and dimming functions.





Decorator Switches

Specifications

Power Supply	Electrodynamic harvesting	
Inputs/Outputs	• 1 or 2 button rocker switch options • Radio Frequency (RF) transmitter	
Communications	315MHz EnOcean RF transmitter	
Transmission Range	80ft. (25m)	
RF Transmission	On press and release of rocker button	
Dimensions	Single: 4.5" H x 2.75" W x .62" D (114mm x 70mm x 16mm) Double: 4.5" H x 2.75" W x .62" D (114mm x 70mm x 16mm)	
Weight	3.4oz (96g)	
Weight Mounting	3.4oz (96g) Surface mounted on wall (using included mounting screws) Can also be flush mounted by optional use of electrical wall box or low-voltage ring	
	Surface mounted on wall (using included mounting screws) Can also be flush mounted by optional use	
Mounting	Surface mounted on wall (using included mounting screws) Can also be flush mounted by optional use of electrical wall box or low-voltage ring • Indoor use only • 32° to 131°F (0° to 55°C) • 5% to 95% relative humidity	

Ordering information

Item Number	Item Description	Color
X31D1000W3VN	Single Decorator Switch	White
X31D2000W3VN	Double Decorator Switch	White



Verve® Decorator Switches are perfectly suited for retrofit projects. Verve wireless decorator switches allow for seamless integration in an existing space where traditional wired decorator switches are already present. Link them with Verve sensors and controllers for efficient control of lighting and miscellaneous electric loads.



In-Line Switch Module VISM-W



Single Channel Controller X2101F03E3VN



10 Channel Controller X2110HB-W-R

VERVE® LIVING SYSTEMS 877-874-8774 vervelivingsystems.com